

Dell Alienware 14 Power-Adapter Port Replacement

Follow this guide to replace the Power port adapter for the Dell Alienware 14.

Written By: Terrence15



INTRODUCTION

In this guide, we will show you how to remove and replace the Power-Adapter Port.


TOOLS:Pro Tech Toolkit (1)

Step 1 — Close the Display




- WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before You Begin</u>. After working inside your computer, follow the instructions in <u>"After Working Inside</u> <u>Your Computer"</u>.
 - Close the display, and turn the computer over.

Step 2 — Remove the Screws



• Remove the screws that secure the base cover to the computer base.

Step 3 — Slide and Lift the Base Cover




• Slide and lift the base cover off the computer base.

Step 4 — Align the Tabs



 Align the tabs on the NEW base cover with the slots on the computer base and slide the base cover into place.

Step 5 — Replace the Screws




• Replace the screws that secure the base cover to the computer base.

Step 6 — Turn the Computer Over




• Turn the computer over and open the display.

Step 7 — Disconnecting the Battery Cable




- WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in Before Working Inside Your Computer. After working inside your computer, follow the instructions in After Working Inside Your Computer.
 - Disconnect the battery cable from the system-board connector.

Step 8 — Remove the Screws




• Remove the screws that secure the battery to the computer base.

Step 9 — Using the Battery Cable




 Using the battery cable, lift the battery and release it from the tabs on the computer base.

Step 10 — Turn the Computer Over




• Turn the computer over and open the display as far as possible.

Step 11 — The Power Button




 Press and hold the power button for five seconds to ground the system board.

Step 12 — Close the Display




• Close the display and turn the computer over.

Step 13 — Align the Tabs




• Align the tabs on the **NEW** battery with the slots on the computer base.

Step 14 — Align the Screw Holes




 Align the screw holes on the battery with the screw holes on the computer base.

Step 15 — Replace the Screws




• Replace the screws that secure the battery to the computer base.

Step 16 — Connect the Battery Cable




• Connect the battery cable to the system-board connector.

Step 17 — Remove the Screws




- MARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before Working Inside Your Computer</u>. After working inside your computer, follow the instructions in <u>After Working Inside Your Computer</u>.
- CAUTION: To avoid data loss, do not remove the hard drive while the computer is On or in Sleep state.
- A CAUTION: Hard drives are extremely fragile. Exercise care when handling the hard drive.
- (i) NOTE: The secondary hard-drive or solid-state drive is optional and can be installed in the optical drive bay.
- Remove the screws that secure the secondary hard-drive assembly to the computer base.

Step 18 — Lifting the Secondary Hard-Drive




• Carefully lift the secondary hard-drive assembly and then lift the latches to release the secondary hard-drive cable from the system-board connector.

Step 19 — Lifting the Hard Drive



• Lift the secondary hard-drive assembly off the computer base.

Step 20 — Turn the Assembly Over




 Turn the secondary hard-drive assembly over.

Step 21 — Remove the Screw




• Remove the screw that secures the secondary hard-drive assembly to the main bracket.

Step 22 — Remove the Screws




 Remove the screws that secure the secondary hard-drive to the secondary hard-drive bracket.

Step 23 — Slide and Lift the Hard-Drive




• Slide and lift the secondary hard-drive off the secondary hard-drive bracket.

Step 24 — Disconnect the Interposer




• Disconnect the interposer from the secondary hard-drive connector.



Step 25 — Connect the Interposer


• Connect the interposer to the secondary hard-drive connector.

Step 26 — Placing the Secondary Hard-Drive




 Place the NEW secondary harddrive in the secondary hard-drive bracket.

Step 27 — Align the Screw Holes




 Align the screw holes on the secondary hard-drive with the screw holes on the secondary hard-drive bracket.

Step 28 — Replace the Screws




 Replace the screws that secure the secondary hard-drive to the secondary hard-drive bracket.

Step 29 — Align the Screw Hole




 Align the screw hole on the secondary hard-drive assembly with the screw hole on the main bracket.

Step 30 — Replace the Screw




 Replace the screw that secures the secondary hard-drive assembly to the main bracket.

Step 31 — Turn the Hard-Drive Assembly Over




• Turn the secondary hard-drive assembly over.

Step 32 — Slide the Hard-Drive Cable




 Slide the secondary hard-drive cable into the system-board connector and press down on the connector latches to secure the cable.

Step 33 — Align the Screw Holes




 Align the screw holes on the secondary hard-drive assembly with the screw holes on the computer base.

Step 34 — Replace the Screws




• Replace the screws that secure the secondary hard-drive assembly to the computer base.

Step 35 — Disconnecting the Status-Light Board Cable



- MARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before Working Inside Your Computer</u>. After working inside your computer, follow the instructions in <u>After Working Inside Your Computer</u>.
- Lift the connector latch and pull the pull-tab to disconnect the status-light board cable from the system-board connector and slide the cable into the slot on the computer base.

Step 36 — Remove the Screws




 Remove the screws that secure the palm -rest assembly to the computer base.

Step 37 — Turn the Computer Over




• Turn the computer over and open the display as far as possible.

Step 38 — Pry the Palm-Rest Assembly




• Using a plastic scribe, pry the palm-rest assembly from the computer base.

Step 39 — Lift the Palm-Rest Assembly




• Carefully lift the palm-rest assembly and turn it over.

Step 40 — Release the Connector Latches




• Release the connector latches to disconnect the flexi-cable from the system board.

Step 41 — Follow the Instructions




- Follow the instructions from step 1 to step 9 in <u>Removing the Keyboard</u>.
- Follow the instructions from step 1 to step 4 in <u>Removing the Status-Light Board</u>.
- Follow the instructions from step 1 to step 4 in <u>Removing the Speakers</u>.
- Follow the instructions from step 1 to step 4 in <u>Removing the Power-Button Board</u>.

Step 42 — Follow Instructions



- Follow the instructions from step 1 to step 4 in <u>Replacing the Power-Button Board</u>.
- Follow the instructions from step 1 to step 3 in <u>Replacing the Speakers</u>.
- Follow the instructions from step 1 to step 4 in <u>Removing the Status-Light Board</u>.
- Follow the instructions from step 1 to step 8 in <u>Replacing the Keyboard</u>.


Step 43 — Connect the Flexi-Cable



• Connect the flexi-cable to the connector on the system board.


This document was generated on 2022-04-07 05:10:30 AM (MST).

Step 44 — Turn the Palm-Rest Assembly




 Turn the NEW palm-rest assembly over and slide the status-light board cable through the slot on the computer base.

Step 45 — Align the Palm-Rest Assembly




• Align the palm-rest assembly over the computer base and snap the palm-rest assembly into place.

Step 46 — Close the Display




• Close the display and turn the computer over.

Step 47 — Replace the Screws



• Replace the screws that secure the palm-rest assembly to the computer base.

Step 48 — Slide the Status-Light Board Cable



 Slide the status-light board cable into the system-board connector and press on the connector latch to secure the cable.

Step 49 — Disconnecting the Tron-Light Cable



- WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before Working Inside Your</u> <u>Computer</u>. After working inside your computer, follow the instructions in <u>After Working Inside Your</u> <u>Computer</u>.
 - Disconnect the tron-light cable from the system-board connector.

Step 50 — Disconnect the Tron Light




• Disconnect the tron light from the optical fibre.

Step 51 — Remove the Screw



 Remove the screw that secures the power-adapter port bracket to the computer base.

Step 52 — Lift the Power-Adapter Port



• Lift the power-adapter port bracket and keep it aside.

Step 53 — Disconnecting the Power-Adapter Port Cable



• Disconnect the power-adapter port cable from the system-board connector.

Step 54 — Lifting the Power-Adapter Port



• Lift the power-adapter port off the computer base.

Step 55 — Align the Power-Adapter Port




• Align the **NEW** power-adapter port with the slot on the computer base and slide the power-adapter port into place.

Step 56 — Connect the Power-Adapter Port Cable



 Connect the power-adapter port cable to the system-board connector.

Step 57 — Align the Screw Hole



• Align the screw hole on the power-adapter port bracket with the screw hole on the computer base.

Step 58 — Replace the Screw



 Replace the screw that secures the power-adapter port bracket to the computer base.

Step 59 — Connect the Tron Light



• Connect the tron light to the optical fibre.

Step 60 — Connect the Tron-Light Cable



• Connect the tron-light cable to the system-board connector.

To reassemble your device, follow these instructions in reverse order.