



Toilet Tree TTP-TRIM-1 Battery Replacement

Follow this guide to replace used battery on Toilettree nose & ear trimmer.

Written By: samuel fontanez



INTRODUCTION

When the device's battery begins to fail follow these steps to restore power to your trimmer.



PARTS:

- [AA Batteries](#) (1)
-

Step 1 — Battery



- Twist the battery cap found on the bottom of the device counterclockwise.

Step 2



- Remove the battery

To reassemble your device, follow these instructions in reverse order.