



# iMac Intel 21.5" EMC 3068 Display Assembly Replacement

Prereq-only guide to remove the entire display...

Written By: Adam O'Camb



# INTRODUCTION

Prereq-only guide to remove the entire display assembly.

---

## TOOLS:

Spudger (1)

iMac Opening Wheel (1)

Plastic Cards (1)

Tweezers (1)

iMac Service Wedge (1)


---

## Step 1 — Display Assembly Separation



- Lift the display up to a near-vertical position.
- ① At this point there is still a strip of adhesive along the bottom of the display that will hold the display to the frame like a hinge. You can loosen this adhesive by working the display up and down a few times.

## Step 2



**⚠ Be very careful not to touch the capacitor leads or any exposed solder joints on the back of the power supply (boxed in red).**

- Grasp the small tab at the end of one of the bottom edge display adhesive strips and pull the adhesive toward the top of the iMac to remove it.
  - Repeat this step with the other adhesive strip and remove it.
- i** If either adhesive strip breaks before it's removed, use a [plastic card](#) to slice through the remaining adhesive.

## Step 3



- Lift the display up from the frame and remove it from the iMac.
- It may be necessary to slowly lift from one side to peel against the remaining adhesive.

**⚠ Be very careful handling the display—it's big, heavy, and made of glass.**

- ☑ After the adhesive is cut, it cannot be used to re-seal the display in place. Follow [this guide](#) to replace the adhesive strips that secure the display to the rear enclosure.

---

To reassemble your device, follow these instructions in reverse order.