



Alienware Aurora M9700 Battery Replacement

Replace the battery in an Alienware Aurora M9700.

Written By: Jasmine Anchondo



INTRODUCTION

This guide provides instructions on how to replace the battery in an Alienware Aurora M9700.

Step 1 — Battery



- Turn laptop over so that the bottom of the device is facing upward.
- Locate the square battery pack on the bottom left corner.

Step 2



- Notice a unlock emblem directly above the battery pack with a sliding lock button.
- Using your finger, slide the button to the right, releasing the battery from its designated compartment.

Step 3



- Now that the battery is free, use your finger to pry the battery upward, out of its designated compartment.

To reassemble your device, follow these instructions in reverse order.