



Sharp Aquos Serie mini SHV31 SIM Card Replacement

How to replace a Sharp Aquos Serie mini SHV31 SIM card.

Written By: Oscar Perez Natareno



INTRODUCTION

When doing this action, remember to power the device down to ensure software recognizes the SIM card. Fixing the SIM card is simple and requires no additional tools.

Step 1 — SIM Card



- Remove the SD/SIM card cover.

Step 2



- Locate the SIM card tray.

Step 3



- Make sure SIM card is debris free and placed properly on the tray.

To reassemble your device, follow these instructions in reverse order.