

HP ProBook 440 G1 Battery Replacement

This guide will show you how to replace the battery of a HP ProBook 440 G1.

Written By: Ethan A Courtney



INTRODUCTION

This guide will show you how to replace the battery of a HP ProBook 440 G1.



PARTS:

• HP ProBook 440, 445, 450, 455, and 470 Replacement Battery (1)

Step 1 — Battery





- Make sure the laptop is turned off before you start.
- Push and hold the release tab on the right and left toward the center.

Step 2





Pull the battery out.

To reassemble your device, follow these instructions in reverse order.