



HP Windows Mixed Reality Controllers TPC-Q044 Battery Replacement

This guide goes over removal/replacement of the HP Windows Mixed Reality Controllers TPC-Q044 batteries.

Written By: Clement Cheung



INTRODUCTION

This quick guide goes over how to remove the piece that covers the battery compartment.

Be sure to have two AA batteries nearby and ready to be put into the device.

There are no potential hazards and no tools are needed for this guide.

Step 1 — Batteries



- Slide the rear compartment cover in the direction of the arrow.
- ☑ If replacing batteries, ensure the (+) and (-) on the battery match the (+) and (-) labeled in the battery compartment.

To reassemble your device, follow these instructions in reverse order.