



Dell Latitude E7440 Battery Replacement

How to replace the battery in a Dell Latitude E7440.

Written By: Akash Kedia



INTRODUCTION

You may have noticed that your device no longer powers on or no longer functions without being plugged in. Laptop batteries naturally degrade with use, losing the ability to hold a full charge. Luckily, Dell designed the Latitude E7440's battery to be easily replaceable.



PARTS:

- [Dell Latitude 7000/E7440 11.1V Replacement Laptop Battery](#) (1)

Step 1 — Prepare the laptop



- Power off your laptop before starting.
- Flip the device over so that the vents on the bottom are facing away from you.

Step 2 — Release the battery



- Place your finger on the latch located in the center of the laptop.
- Slide the latch to the right, applying enough force to reveal a red indicator.
- ⓘ You will hear a soft click when the latch has been disengaged.

Step 3 — Remove the battery



- Lift the battery by the top, away from the laptop body.

To reassemble your device, follow these instructions in reverse order.