



---

## INTRODUCTION

The mother board inside the remote has outlines of buttons that are actually on the controller. By pressing these down, it sends commands to the mother board caused by electricity to carry out the actions the player wants. Batteries are the main source of power for the functions.

---

### TOOLS:

- [Tri-point Y0 Screwdriver](#) (1)
  - [Spudger](#) (1)
  - [Tweezers](#) (1)
-

To reassemble your device, follow these instructions in reverse order. I am planning on posting a reassemble guide in the future as well, be prepared!