



Audio Technica ATH-AD500 3-D Wings Replacement

If your headphones are not staying on due to damaged 3-D wings, replace the 3-D wings.

Written By: Melanie Reis



INTRODUCTION

This installation guide will help you replace the 3-D wings.



PARTS:

- [Replacement 3-D wing](#) (1)
-

Step 1 — 3-D Wings



- Remove the 3-D wing by pushing down on the bar which the wing is connected to while simultaneously pushing up on the wing.

To reassemble your device, follow these instructions in reverse order.