

Chevy s10 extreme pickup truck 1999

How to do a oil change in a 1999 chevy s10 extreme pickup truck.

Written By: Eddie G





TOOLS:

- Torque Wrench (1)
- Socket 16mm (1)
- Hydraulic Floor Jack (1)
- Jack Stands (1)
- Oil Drain Pan (1)
- Funnel (1)
- Oil Filter Wrench (1)



PARTS:

- Oil Filter (1)
- Motor Oil 1qt 10W-30 (4)

Step 1 — Lift up truck





- There are two metal bars across the passenger and driver side to lift the car with a jack.
- Make sure to have a tire or scissor lift gate under vehicle to not fall under while working
- (i) Have something block back tires from moving.

Step 2 — Remove old oil



- Its a 16 mm nut
- After all oil has drain reinsert the 16mm nut back and clean around it.
- i Have a bucket or container to collect the oil.

Step 3 — change the oil filter



- The filter can be seen from the tire.
- Apply the new filter with a dab of oil around the top for lubrication.
- i If filter is hard to get loose consider buying a oil filter wrench.

Step 4 — Add oil



- Add 4 qt of oil
- Check under vehicle to make sure there is not oil spilling.

Congratulation you have successfully done your first or another oil change.