



Removing Creative Zen Vision W Battery

This guide will show you how to remove the...

Written By: Tim Wilson



INTRODUCTION

This guide will show you how to remove the battery pack from the device. You may want to do this if your battery is not working properly.

PARTS:

[BAC0603R79923 Battery](#) (1)

Step 1 — Battery Removal



- Push the black button and slide the battery casing to the left simultaneously, until the battery is completely separated from the device.
-

To reassemble your device, follow these instructions in reverse order.