



PlayStation VR Microphone Replacement

This guide shows you how to disassemble and replace the microphone on your Playstation VR headset.

Written By: Elliott Ruoff



INTRODUCTION

This guide shows you how to disassemble and replace the microphone on your Playstation VR headset.

TOOLS:

- [iFixit Opening Tool](#) (1)
 - [Phillips #000 Screwdriver](#) (1)
-

Step 1 — LED Light Tracker




- Peel back the rubber covering around the lenses to remove the surrounding plastic eyepieces.

Step 2



- Unscrew four 13 mm screws with a PH #000 screwdriver.

Step 3



- Using the plastic opening tool, carefully pry the white plastic panel free from the side of the headset. Repeat this action for the opposite side.

Step 4



- Use the plastic opening tool to pry the top white plastic panel free from the headset.
- ⓘ Do not try to remove the bottom plastic panel. There is a screw attaching it that must be removed first.
- ⓘ There may be a small amount of adhesive attaching the top panel to the headset, in which case you may need to use a bit more force to remove the panel.

Step 5



- Flip the headset over.
- Using a PH #000, unscrew the 7 mm screw found on the bottom of the headset.

Step 6



- Using the plastic opening tool, pry the bottom white plastic panel loose and remove it from the headset.
- ⓘ There is adhesive attaching the panel to the headset, in which case it will take more force to remove the panel.

Step 7




- Unscrew the two 7 mm screws from the top of the headset.

Step 8




- Using your fingers, carefully pry the black front panel free from the headset.
- ⓘ We recommend that you start the removal from the sides by pulling them forward.
- ⓘ There is adhesive holding the front panel in place, which means you will need a bit of extra force to remove it.

Step 9




- Unscrew the four silver 6 mm screws in each corner using a PH #000 screwdriver.

Step 10



- Lift the small silver latch attaching the ZIF (zero insertion force) connector to the circuit board.
- Carefully pull the end of the white ribbon connector from its slot.
- ⓘ Be careful not to damage or dirty the ribbon connector.

Step 11




- Unhitch the yellow led connector ribbon and move it aside.
- ⓘ Be careful not to damage or dirty the ribbon connector.

Step 12



- Carefully pry the black plastic piece attaching the yellow ribbon to the headset away from the green circuit board.
- Remove the yellow LED ribbons and black plastic connecting piece from the headset.

Step 13 — Microphone



- Pinch the small white cable connector and unplug it from the motherboard.
- The microphone will be attached to the white cable connector on the bottom right of the motherboard.

To reassemble your device, follow these instructions in reverse order.