

# **Disassembling Nokia 3395 Keypad**

Removing the keypad.

Written By: Nico Lee



#### INTRODUCTION

Removing the keypad.

### Step 1 — Back Case







- Turn the phone off.
- Hold the phone, and gently press the white button located at the bottom of the phone.
- While pressing the button, slide the back plate upwards, opening the plate.

#### Step 2 — Front Case





- Push the two black buttons on the side with your thumbs forward. This will release the front faceplate.
- Flip over the device, and pry the faceplate away.

## Step 3 — Keypad



Remove keypad from under the face plate.

To reassemble your device, follow these instructions in reverse order.