



Repairing Apple Wireless Keyboard Power Button

If you drop your keyboard at the upper right corner, your power button might get stuck and the keyboard will not work any longer. This is a short guide which will show you an easy way to get it working again!

Written By: Peter Alt



INTRODUCTION

If you drop your keyboard at the upper right corner, your power button might get stuck and the keyboard will not work any longer.

This is a short guide which will show you an easy way to get it working again!

TOOLS:

- [iFixit Tech Knife](#) (1)

Step 1 — Power Button



- Cut away the dented aluminum with your cutting knife. It's a little bit tricky and you have to use some force to cut it, but it will work.
- Please be carefull with the knife! You can cut into your thumb very easily!

Step 2



- Carefully pull out the power button if needed and correct the dent
- Push the power button back in once the dent is smoothed out from inside.

Once the aluminum that was holding the button in is cut away, your device is repaired. No reassembly is necessary.

