



# Krups 963 Bottom Panel Removal

Removing the bottom panel/cover of the machine.

Written By: Wyatt Hall



---

# INTRODUCTION

Prerequisite Only



## TOOLS:

- [Phillips #2 Screwdriver](#) (1)
  - [Phillips #0 Screwdriver](#) (1)
-

## Step 1 — Removing Bottom Screws




- ⚠ Make sure the device is unplugged before continuing.
- Use a Phillips size 2 screwdriver to remove the four 12mm screws found on the bottom of the machine.

## Step 2



- Remove the single black Phillips size 0 10mm length screw on the back of the machine.

### Step 3



- Remove the bottom cover from the machine and slide it down the power cord.

To reassemble your device, follow these instructions in reverse order.