



# Samsung HMX-QF20 Battery Replacement

Replace the dying battery to get power back on the camcorder.

Written By: Ian Dorset



---

## INTRODUCTION

Before replacing, check to see if the battery is fully charged. Make sure the replacement battery is the correct model. The battery should be a BP 125A Rechargeable Li-ion Battery.

---

### TOOLS:

- [Phillips #00 Screwdriver](#) (1)
-

## Step 1 — Battery



- Locate the battery slot on the underside of the camcorder.

## Step 2



- Locate the arrow marked on the battery slot door and push in the direction the arrow points to open the latch.

### Step 3



- Release the latch and allow it to fully open.
- Insert the battery following the diagram marked on the edge of the battery slot.

To reassemble your device, follow these instructions in reverse order.