



Acer Aspire One 722 Battery Replacement

A guide on how to replace the battery on the Acer Aspire One 722.

Written By: Christian Barboza



INTRODUCTION

It's recommended to change Acer Aspire One 722 batteries after approximately one year of use. Normally a fully charged Acer Aspire One 722 battery will support the system for 7 hours, but as the batteries' lifetime goes down it needs to charge frequently. [Take this precaution](#), if your battery gets swollen. But it's better to replace the battery before it gets swollen.

Use this simple guide to replace your Acer Aspire One 722 battery. Follow these 5 easy steps which will take no longer than 3 minutes and restore your Acer laptop to like-new performance.

Step 1 — Battery



- Power down the netbook by pressing the power button on the top left corner.

Step 2



- Close the netbook and flip it over so that the back is facing up.

Step 3



- Slide the button below the battery to the right while simultaneously pulling the battery out.

Step 4



- If necessary, remove the old battery and replace it with a new one.

Step 5



- ✦ Check the thin grooves on the side of the battery entry and line the replacement battery up to the grooves.

To reassemble your device, follow these instructions in reverse order.