



Frigidaire FFPE45B2QM Refrigerator Door Replacement

This guide is aimed to show users how to replace a broken or damaged door that may be effecting the performance or temperature of this refrigerator.

Written By: Peterluchini





TOOLS:

- [Metal Spudger](#) (1)
 - [JIS #1](#) (1)
-

Step 1 — Broken Hinge



- Carefully pop off the cover using a spudger or other opening tool.

Step 2



- Use a JIS #1 screw driver to remove both 25mm bolts that are attaching the door to the refrigerator.

Step 3



- Remove the damaged hinge. Make sure that you don't lose the bolt that goes into the door.

Step 4 — Refrigerator Door



- Remove the door by slowly lifting straight up, put the door off to the side.

Step 5



- Get a new, non-damaged door.

To reassemble your device, follow these instructions in reverse order.