



Fujifilm X-M1 Lens Assembly Replacement

This guide will show you how to replace the lens assembly on the Fujifilm X-M1.

Written By: Kelsea Weber



INTRODUCTION

This guide will show you how to replace the lens assembly on the Fujifilm X-M1.

We highly suggest you use a [magnetic project mat](#) or an organization tray. This camera has **many** different types of screws and keeping them organized is key to proper reassembly.




TOOLS:

- [Phillips #000 Screwdriver](#) (1)
 - [Tweezers](#) (1)
 - [Magnetic Project Mat](#) (1)
-

Step 1 — Battery



- Turn the camera upside down to locate the battery compartment.
 - Slide the button up to open the compartment.
 - Slide the orange button up to release the battery.
-  The battery is not shown in these photos.

Step 2 — Lens Assembly



- Twist the lens cap to remove it from the camera.
- Remove the six 6.5 mm Phillips screws from the front of the lens assembly.
- Use tweezers to remove the top metal ring and the thin metal ring below it .

Step 3



- Remove the four 4.3 mm Phillips screws inside the lens assembly.

To reassemble your device, follow these instructions in reverse order.