



Removing HP Pavilion zd8000 WiFi Card Cables

Removing the WiFi cables is essential for...

Written By: Allie Menard



INTRODUCTION

Removing the WiFi cables is essential for further disassembly of the laptop.

TOOLS:

Phillips #1 Screwdriver (1)

Tweezers (1)

Step 1 — Battery



- Slide the battery release latch towards you.

Step 2



- Pull up on the battery to remove it.

Step 3 — WiFi Card Cables



- Unscrew the four 8mm Philips screws marked with an icon resembling a stacks of discs.
- Lift the cover from the right to remove it.

Step 4



- Use tweezers to detach the grey and black cables connected to the green WiFi card.

To reassemble your device, follow these instructions in reverse order.