

# **Kyocera Hydro Vibe Trim Replacement**

This guide will walk readers through the process of replacing the trim for the Kyocera Hydro Vibe.

Written By: Phillip Newman



## **INTRODUCTION**

If the trim becomes damaged, it may require replacement or repair. This guide will show you how to replace or repair the trim on your device.



## **TOOLS:**

- iFixit Opening Tools (1)
- Metal Spudger (1)
- Screwdriver (1)

#### Step 1 — Battery



- Make sure that the device is turned off before beginning.
  - Look for a small indentation on the bottom of the phone.
- Insert the plastic opening tool into the indentation and lift off the back casing.

#### Step 2







- The large white component is the battery. Look for a small indentation under the arrow that says "LIFT."
- Place the plastic opening tool in the indentation and lift the battery out of the socket.

# Step 3 — Trim



- Locate the screws holding the trim which are the four side screws on each corner.
- Remove each screw with a Phillips screw driver #J00. The screws are 5mm Phillips.

#### Step 4





- Locate the clasps holding the trim in place.
- You will need to insert the metal spudger through the bottom of the trim and slowly push upwards to release the clasps.

# Step 5



- The trim is flimsy.
- This is what the trim will look like once removed.

To reassemble your device, follow these instructions in reverse order.