



Nokia 3310 LCD Replacement

This guide will help you fix your Nokia 3310 LCD. This can also be used on Nokia 3390.

Written By: Tay



INTRODUCTION

This guide will help you fix your LCD on a Nokia 3310 or 3390.

Step 1 — LCD



- First, remove the rear cover

Step 2



- Remove the front cover and the keyboard

Step 3



- Remove the metal casing

Step 4



- Remove the LCD

Step 5



- Once you put in the new one, put everything back together

To reassemble your device, follow these instructions in reverse order.