GoPro HD Hero2 Battery Replacement

GoPro HD Hero2 battery replacement.

Written By: David Hodson

This document was generated on 2020-11-13 11:35:11 PM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 1 of 4

INTRODUCTION

Replace your dying GoPro battery with a fresh one. If you're ready to jump off a mountain, your battery should be too!

🔧 **TOOLS:**

- iFixit Opening Tools (1)

⚙ **PARTS:**

- GoPro Hero2 Replacement Battery (1)

This document was generated on 2020-11-13 11:35:11 PM (MST).

www.iFixit.com

Step 1 — Back Cover

- Place your thumb on the indentation in the back case on the side of the GoPro.

- Gently press down with your thumb and lift the back cover away from the case to remove it.

Step 2 — Battery

- Slide a plastic opening tool between the battery and the rear case.

- Gently pry the battery up and out of the rear case.

This document was generated on 2020-11-13 11:35:11 PM (MST).

Step 3

- Remove the battery from the case.

To reassemble your device, follow these instructions in reverse order.