

Samsung Galaxy J1 Logic Board, Main Camera, Front Camera, Earpiece, Loudspeaker Replacement

Samsung Galaxy J1 Logic Board, Main Camera, Front Camera, Earpiece, Loudspeaker Replacement

Written By: ZFix



INTRODUCTION

How to disassemble Samsung GALAXXY J1 / SM-J100

[video: https://www.youtube.com/watch?v=Doj2ymukO2A]



TOOLS:

- Phillips #00 Screwdriver (1)
- iFixit Opening Tools (1)

To reassemble your device, follow these instructions in reverse order.