IFIXIT

Main access cover

Written By: Felice Suglia

Step 1 — Battery

- Open the latch on the right side that secures the battery in place.

- Open the latch on the left side that secures the battery in place.

- Now remove the battery.

Step 2 — Main access cover

- Using a Philips-head screwdriver remove highlighted screws.

- Look at the marking to see how to remove the access cover.

- Remove the access cover as shown by the marker.

Step 3

- You now have access to all components of this laptop.

To put the device back together, follow these steps in reverse order.