




Lenovo Ideapad Yoga 2 11 Speakers Replacement

How to remove and replace the speakers for your Lenovo Ideapad Yoga 2 11".

Written By: Andria Chen



INTRODUCTION

If your speakers no longer work correctly, this guide will teach you how to remove the laptop's speaker.

TOOLS:


- [T5 Torx Screwdriver](#) (1)
 - [Tweezers](#) (1)
 - [Phillips #000 Screwdriver](#) (1)
-

Step 1 — Back Panel



- Begin by turning your closed laptop so that you are looking at the bottom panel.

Step 2




- Locate the 10 screws (6mm) around the border of the panel.
- Using the Torx T5 Screwdriver, remove the screws.

Step 3




- Now that the screws are removed, gently lift the back panel upwards to detach it from the rest of your laptop.

Step 4 — Speakers





- Remove 2 screws (2mm) from each of the speakers, 4 screws total, using the PH #000 screwdriver.

Step 5




- Locate the connecting cables.

Step 6



- Unclip the cables by pulling downwards gently using tweezers.

Step 7



- After the cables are disconnected, remove the speakers by lifting the speakers up.

To reassemble your device, follow these instructions in reverse order.