


# Sprint Sanyo RL-4920 Vibrator Motor Replacement

Replace the vibrating motor to restore your phone's vibrating capabilities.

Written By: Austin Shores



This document was generated on 2020-11-28 03:06:51 AM (MST).



- 64 Bit Driver Kit (1)
- iFixit Opening Tools (1)
- Spudger (1)

#### Step 1 — Back of Phone



 Flip the phone over so that the screen is facing down.

#### **Step 2** — Remove Battery Pack





- Push the gray lever up towards the top of the phone.
- Pull up on the battery pack and completely separate it from the phone.

#### Step 3 — Screws





- Locate the five screws around the back casing.
- Use a three-prong screw bit to remove all five screws.

# **Step 4** — **Separate Cases**



 Use the plastic opening tool and slide it around the phone to pull apart the front and back casing.

## **Step 5** — **Separate Cases**




Separate the two cases.


## Step 6 — The Front Case



 Use the plastic opening tool to remove the motherboard from the front case.

## Step 7 — Display







Guide ID: 19394 - Draft: 2018-04-04

Locate the 4 white clips of the dispaly.


## Step 8






 Using the plastic opening tool, pull the white clips of the display away from the printed circuit board to unclip display.

#### Step 9





Sprint Sanyo RL-4920 Vibrator Motor Rep..



Grasp the display on both sides and carefully pull the display off of the printed circuit board.


## Step 10






- Using the plastic opening tool, carefully remove the yellow film covering the display connector.
  - (i) Do not damage the yellow film. Ensure that it stays in one piece and does not tear.


## **Step 11 — Vibrator Motor**




 Use a Phillips-head screw bit to remove the screw under the yellow film

# Step 12









- Use the spudger tool to pry the latches ways from the circuit board
- Detach the metal casing from the circuit board


#### Step 13







A Remove wires attaching vibrator motor to circuit board gently so as not to damage them

# Step 14








- Once the metal casing is removed from the circuit board take it and locate the vibrator motor on the top side of the casing
- Use the spudger tool to gently pry the vibrator motor out of its protective shell

# Step 15



 With the vibrator motor completely removed, you can now replace it with a new one

To reassemble your device, follow these instructions in reverse order.