


Motorola G2 (G second Generation) Ear piece speaker Replacement

Before you begin, download the Rescue and Smart...

Written By: Robin Taylor



INTRODUCTION

Before you begin, download the <u>Rescue and Smart Assistant</u> app to backup your device and diagnose whether your problem is software or hardware related.


🖌 TOOLS:

T5 Torx Screwdriver (1)

PARTS:

Moto G Second Generation Speaker (1) Motorola Cell Phone Speaker

Step 1 — Remove the back cover




 Remove the phone's back cover A thumb nail or similar will remove it. You will have done this when you inserted a SIM or MicroSD card.

Step 2 — Remove the T5 torx screws from the back case




- Remove Your SIM card(s) and MicroSD card (if installed). Put them somewhere safe.
- Remove the screws highlighted using a T5 Torx driver, (A T6 will remover them but will require force and mess up the heads!)

Step 3 — Remove the back of the case collect up the screws.



- Once the phone is open some screws may remain in the back case. They are small and easily lost! Be sure to collect them up and store them in a container for re-assembly.
- You may also want to put the two buttons away safely as they may drop out.
- Note the speaker, show an arrow, can be removed without further disassembly.




- Remove the speaker by **lifting it** using a screwdriver or similar tool. **Note** It is only held in by adhesive tape. Take your time, especially if you are removing a donor speaker from a broken phone. **If you push in,** as the speaker lifts the tool will slide under the speaker damaging its surface!
- The second image shows the front of the good replacement speaker I used.
- Note: Both speakers in the phone are identical. If you mess up removing a donor speaker you get a second chance!



- If you are using a used donor part the adhesive tape will probably be damaged. I put the speaker in place, applied a thin strip of two part epoxy resin along its right edge. You can use silicone sealant or any other adhesive you deem safe.
- My speaker will be more difficult to remove than if I had used silicone sealant which if flexible strong but can be cut easily. It is also more messy....

Step 6 — Reassemble and Test.



• Your finished! Reassemble, note the side buttons fit in the case as show.

To reassemble your device, follow these instructions in reverse order.