



Classen Over Seeder TS20HD 2012 Cable Assembly Replacement

Cable assembly C100053

Written By: Trevor A



Step 1 — Cable Assembly C100053



- Remove one 7/16 standard nut securing cable

Step 2



- Remove old cable with needle nose pliers hook the new one on the same way. Tighten the new cable into place with the 10mm adjustment nuts at the bottom then reassemble the top portion

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2021-11-25 07:16:46 PM (MST).

