



iPad 3 Wi-Fi Power & Volume Button Assembly Replacement

Internal Prereq.

Written By: Walter Galan



INTRODUCTION

Internal Prereq.



TOOLS:

- [Phillips #0 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
 - [Spudger](#) (1)
-

Step 1 — Power & Volume Button Assembly



- Remove the following screws securing the power & volume button cable to the aluminum frame:
 - Two 5.5mm Phillips #0
 - One 2.6 mm Phillips #0
 - Two 2.6 mm Phillips #0
- ☑ These screws are angled into the aluminum frame. Be sure to always hold the screwdriver in line with the screw.

Step 2



- Remove the piece of plastic covering the volume buttons.

Step 3



- Remove the single 2.6 mm Phillips #00 screw holding the volume button frame to the aluminum frame.
- ⓘ This screw is angled into the aluminum frame. Be sure to always hold the screwdriver in line with the screw.

Step 4



- Wedge the edge of a plastic opening tool underneath the sleep/wake sensor, being careful to not damage the fragile cable.
- Move the plastic opening tool around the sensor, releasing the adhesive.

Step 5




- Continue sliding the plastic opening tool underneath the power & volume cables, releasing the adhesive.

Step 6



- Using the tip of a spudger, release the adhesive underneath the volume button branch of the ribbon cable.

Step 7



- Continue sliding the tip of the spudger toward the top of the iPad, releasing the adhesive.

Step 8



- With the tip of the spudger still underneath the ribbon cable, gently lift the power button out of its socket in the aluminum frame.

Step 9



- Holding the power & volume button cable with both hands, carefully pull the volume buttons and lock switch from their sockets in the aluminum frame.
- Lift and remove the power & volume button cable out of the rear aluminum case.

To reassemble your device, follow these instructions in reverse order.