




Lenovo Yoga 710-14IKB Trackpad Replacement

Guide to replace the trackpad of your Lenovo Yoga 710-141KB.

Written By: Chuefeng Vang



INTRODUCTION


This guide will teach you to remove and replace your trackpad.



TOOLS:

- [T4 Torx Screwdriver](#) (1)
 - [iFixit Opening Tool](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
 - [JIS #1](#) (1)
-

Step 1 — Back Cover



⚠ Ensure your device is completely OFF before starting this guide.

- Use a Torx T4 screwdriver to unscrew the nine 5 mm screws holding the cover in place.

- Use a Torx T4 screwdriver to unscrew the 8 mm screw in the center.

⚠ When reassembling, make sure not to tighten the screws too much or you may risk cracking the plastic cover.

Step 2



- Use the plastic opening tool to pry the cover up and away from the laptop, starting at one end and working your way around the cover.

i The cover is large and flat and made of thin plastic. It cracks easily, so make sure not to pry too hard.

Step 3 — Battery



- Use a Phillips #00 screwdriver to remove the four 3 mm screws holding the battery in place.
- ⓘ Be careful not to cross-thread the screws. Also, don't let the screws fall down into the laptop case.

Step 4




- Use your fingers or an opening tool to slide the battery connector out of its motherboard socket.

Step 5




- Remove the battery.

Step 6 — Trackpad



- Use the Phillips #1 screwdriver to take off the three 3mm screws.


Step 7



- Grip the blue tab and pull out.

⚠ Careful to not pull too hard, there is a chance of damaging the tab.

Step 8



- Lift off the layer of tape from the trackpad.

Step 9



- Push out the trackpad.

To reassemble your device, follow these instructions in reverse order.