



Lenovo ThinkPad X1 Yoga Speaker Replacement

This guide is to remove and replace the speakers on the Lenovo ThinkPad X1 Yoga.

Written By: Sam Lanning



INTRODUCTION

This guide is to remove and replace the speakers on the Lenovo ThinkPad X1 Yoga (Model Number: 20FQ005YUS). If your computer's sound is scratchy, too quiet, or gone altogether, your speakers will need to be replaced.

Be sure to power off the computer and unplug from its charger before beginning this guide.



TOOLS:

- [Phillips #1 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
 - [Tweezers](#) (1)
-

Step 1 — Back Cover



i Be sure to power off and unplug your device before you begin your repair.


- Flip the computer over so the bottom is facing up.
- Remove nine 4mm Phillips #1 screws from the bottom of the computer.
- Use an iFixit opening tool to pry the back cover off of the laptop.

Step 2 — Speakers





- Remove the five 4.5mm Phillips #1 screws that secure the battery.

Step 3



- Using a pair of tweezers, push the sides of the white speaker wire toward the battery (where it says Lenovo) to unplug it.

Step 4



- Remove the speakers from either side of the battery. The connecting wire will unthread from the sides of the battery.

To reassemble your device, follow these instructions in reverse order.