


# Razer DeathAdder Chroma Motherboard Replacement Guide

This guide will inform you how to remove and isolate the Razer DeathAdder Chroma motherboard from the device casing.

Written By: Nathan D. Kappler



# INTRODUCTION

The Razer DeathAdder Chroma may experience critical issues related to the device's motherboard. To resolve them, it might be necessary to fix components below the motherboard.

# **TOOLS:**

- Spudger (1)
- Phillips #0 Screwdriver (1)
- Phillips #000 Screwdriver (1)

# Step 1 — Outer Casing



- (i) Opening the mouse casing will void any warranty that exists for the mouse.
  - Turn the mouse over so the bottom is facing up.

## Step 2



• Use the blunt end of the spudger to pry the adhesive rubber pads from the top left and right edges.



Use a Phillips #0 screwdriver to remove two 6.7 mm screws.



## Step 4

• Use your fingers to identify the location of the screw under the bottom label.



- Use a Phillips #0 screwdriver to remove one 6.7 mm screw.
- (i) Clear the label away from around the screw for easier removal.

#### Step 6




- Turn the mouse over so the bottom is facing down.
- Separate the top casing from the bottom base by pulling the top casing upwards.
- Separating the casing too quickly could damage the ribbon connector between the motherboard and the LED lights.




- Disconnect the ribbon connector between the motherboard and the LED lights by pulling upward.
- A Pulling too hard could damage the wire connections.

## Step 8 — Motherboard




• Disconnect the ribbon connector between the motherboard and the USB cable by pulling upward.




• Use a Phillips #0 screwdriver to remove three 5.5 mm screws.

# Step 10




• Use a Phillips #0 screwdriver to remove two 11.5 mm screws on the side buttons.



• Use a Phillips #000 screwdriver to remove one 5.0 mm screw.

# Step 12



• Disconnect the ribbon connector between the motherboard and the optical sensor.



• Remove the motherboard by grasping the sides and gently pulling upward.

To reassemble your device, follow these instructions in reverse order.